

To pair the Odyssey app on your mobile device to the OdysseyLink:

1. Press the pairing button on the OdysseyLink. The LED will start flashing green, activating a 30-second window to undertake pairing with your mobile device.



2. Launch the Odyssey App on your device and press the "Scan" button. The Odyssey App will search for nearby OdysseyLink devices. Once this is complete, a list of the available OdysseyLink devices ready for connection will appear.
3. Select the device that corresponds to the last six digits of the serial number of the OdysseyLink you wish to pair.
4. After a successful connection, the LED status indicator on the OdysseyLink will turn OFF and the Bluetooth icon in the Odyssey App will no longer be crossed out.